SPS Motorsport GmbH Im Petersfeld 4 65624 Altendiez Telefon: 06432/6409960 Fax: 06432/6409966

Web: http://sps-motorsport.com E-Mail: info@sps-motorsport.com



Installation instructions

Sideskirts Mazda MX-5 NA/NB/NBFL

Date:	13.12.2021	Revision:	0
Editer:	Nico Hafner	Vehicle:	Mazda MX-5
			NA/NB/NBFL

Scope of delivery:

• Sideskirts fitting MX-5 NA/NB/NBFL



Warning:

Please read this instruction before installation and get in touch with the work on the car! Ideally, have the installation done by a professional workshop. Tighten all screws with the torque recommend by the manufacturer. The assembling company is liable for installation mistakes. In case of manufacturing defects, the corresponding components will be replaced without any costs within the warranty period.

Nico Hafner	gez. Nico Hafner
Name of editer	Signature

SPS Motorsport GmbH Im Petersfeld 4 65624 Altendiez Telefon: 06432/6409960 Fax: 06432/6409966

Web: http://sps-motorsport.com E-Mail: info@sps-motorsport.com



Preparation:

- Park the vehicle, switch off the engine and let the engine cool down
- Lift the car up
- Clean the OEM side skirts
- Remove the screws of the lower side of the front fenders

Installation of the side skirts:

- Hold the side skirts on the vehicle and convey them along the full length of the OEM side skirt
- You can use the lower screws of the front fender to install the side skirts. To do this, transfer the bolt pattern of the fender holes to the side skirt and drill them there
- Spread 8 holes over the contact surface between side skirt and OEM side skirt and drill them. For these holes you will later use self tapping screws with a minimum diameter of 4.8mm to fit the side skirts to the car
- Temporarily attach the sideskirt to the car using the two fender screws making sure that the sideskirt is attached to the vehicle in the middle and straight
- Transfer the bolt pattern from the sideskirt to the OEM sideskirt
- Remove the sideskirt from the car
- Drill the holes for the self tapping screws using a 4.0mm drill
- Attach the sideskirt to the car
- Fasten the 4.8mm self tapping screws in the remaining holes
- Repeat the entire process on the other side of the vehicle

Final work on the vehicle:

- Check that the wheels can move freely in all driving conditions
- Control all screws if they are tightened correctly

Nico Hafner	gez. Nico Hafner	
Name of editer	Signature	